

DIY Adirondack Chair

Shopping List:

TOOLS

Compound Miter Saw

Measuring Tape

Speed Square

Drill with Countersink Bit

MATERIALS

1 - 2x4x8'

1 - 1x4x12'

2" and 2 1/2" exterior screws

Cut List:

2 - 2x4 @ 23 1/2" long with both ends cut at 30 degrees off square, parallel to each other, long point to short point measurement (stringers)

5 - 1x4 @ 22 1/2" (top boards)

2 - 2x4 @ 13 3/4" long with one end cut at 30 degrees off square, longest point measurement (legs)

